1 Product Overview

1.1 Product Introduction

The UGEE CS06 Signature Tablet has 4"x 6" active area, weighs 125g with minimum thickness of 2mm. Based on UGEE's patented EMR technology, it supports space resolution of 5080 LPI and pressure sensitivity of 2048 levels, and allows the accurate capture of every handwritten broke. Together with the fee-free UGEE Signature software toolkit, the CS06 provides a low-cost while professional and easy method for the user to sign directly within Microsoft Office and Adobe PDF files. Each device is assigned a unique hardware ID in order to determine which one is used for a particular signature.

CS06 still supports traditional EMR tablet functions, like drawing and playing game.

1.2 Tablet Overview



Image 1.1 Tablet Overview

Notes:

The Tablet should be connected to your computer through the USB Cable before it could be used.

2 Sign in Microsoft Office Files

2.1 Supported Operating System

Windows: 7, 8, 10 (32/64bit) Notes:

1) Disable any the antivirus or firewall software and close any unnecessary background software before starting the installation. Some software, such as OneDrive and Dropbox, may monopolize useful files and prevent a successful installation. On windows computers, please check the system tray on the bottom-right of the desktop and exit any software unrelated to your computer hardware.

2) Uninstall any existing Tablet software before installing new driver. Other Tablet drivers will conflict with this tablet or prevent the installation.

3) You can download the latest driver from the website (https://business.hanvonugee.com/en/driver). If you choose to download the driver from the website, be sure to extract the package if it's compressed as .zip format before running "*.exe" or "*.pkg".

2.2 Supported Microsoft Office versions

1) Microsoft Word 2010 or above;

2) Microsoft Excel 2010 or above;

3) Microsoft PowerPoint 2010 or above

2.3 Install the OfficeAdmin software

1) Connect the tablet to your computer via the corded USB included, and the white LED will be bright.

2) Please download the latest driver from the support folder of our website

(https://business.hanvonugee.com/en/driver).

3) Run the "*.exe" file to start installation. Be sure to extract the package before running "*.exe" if it's compressed as .zip format.

4) Restart your computer after a successful installation. The "UGEE Signature" menu will appear on your Microsoft Word. Click the menu, the shortcut "Signature" will appear as below.

-	5.0	₹							Document1 - Word (Product Activation Failed)		
File	Home	Insert	Design	Layout	References	Mailings	Review	View	UGEE Signature	Foxit Reader PDF	♀ Tell me what y
Signature											

Image 2.1 Signature menu in Microsoft Word

5) Click the Signature button, below popup window will appear.

levice connected		
	01/	
Clear	UK	Cancel

Image 2.2 Signing popup window on PC

6) The user signs on the Tablet. The signature will be displayed on the simultaneously. The user should click [OK] button on the tablet after signing.

device connected		
	IGE	3B
Clear	OK	Cancel

Image 2.3 Signature displayed on the popup window

7) For storing the signature permanently, the user should save the Word documentation before closing it.

3 Sign in PDF Files

3.1 Supported Operating System

Windows: 7, 8, 10 (32/64bit) Notes:

1) Disable any the antivirus or firewall software and close any unnecessary background software before starting the installation. Some software, such as OneDrive and Dropbox, may monopolize useful files and prevent a successful installation. On windows computers, please check the system tray on the bottom-right of the desktop and exit any software unrelated to your computer hardware.

2) Uninstall any existing Tablet software before installing new driver. Other Tablet drivers will conflict with this Tablet or prevent the installation.

3) You can download the latest driver from the website (https://business.hanvonugee.com/en/driver). If you choose to download the driver from the website, be sure to extract the package if it's compressed as .zip format before running "*.exe" or "*.pkg".

3.2 Install the UGEE Sign PDF software

1) Connect the tablet to your computer via the corded USB included.

2) Please download the latest driver from the support folder of our website

(https://business.hanvonugee.com/en/driver).

3) Run the "*.exe" file to start installation. Be sure to extract the package before running "*.exe" if it's compressed as .zip format.



4) After a successful installation, the "UGEE Sign PDF" icon will appear on your PC desktop. Doubleclick the icon to start the program. Open your PDF file. The Signature shortcut in the Quick Access Toolbar becomes active.



Image 3.1 Signature Shortcut

5) Click the Signature shortcut, the cursor of your mouse will become a cross symbol. Left-press you mouse and drag in the PDF file, you'll see below popup window.

Storage Temp Humidity(non-	: -30C to 70C/'-22F to 158 -condensed): Operating 10	F 0% to 90%/Storage 5% to	95%
Electrostatic	show signature		×
EMC Regulat	bloose size here:		
Protection Le	piease sign here:		
Drop Resista			
Part 2- Custo			
Biometric Fin			
customized fi			
Wrist Strap:			
device lock a			
Custom trade			
ousion liade			
Also Tablets			
disk. The tab			
Ministry of He			
			2
			2
		·	15:45:58 2018-06-29 BookxPDF 版权所有
	ok	clear	cancel

Image 3.2 Signing Popup in UGEE Sign PDF

6) The user signs on the tablet, and click [OK] button on the tablet after signing.

7) The signature was inserted into the PDF file, which will be saved automatically.

F to 112F F to 158F ating 10% to 90%/Storage 5% to 95% air discharge,'+ /-BkV contact discharge six sides 1: TCS1(With FBI, FIPS-201,1S019794,ANSI,WSQ, Other

control capability: Remote application control, remote note device tracking

Image 3.3 The signature was inserted into the PDF file

4 Software Uninstallation

4.1 E.g. Windows

Open the Start menu, enter [Settings]->[Apps & Features]. Find the target program and right-click and select [Uninstall]. Follow the on-screen instructions to install it.

Be sure to reboot your computer after the uninstallation procedure is complete.

* If you have any technical questions, please contact us via signature.software@ugee.com.